


RECOMMENDED KITE KNOT:



Kites are supplied with approximately 2m of line - adjust the line length so the kite is about 1.5m - 2m above the crop.



Split ring and swivel




150mm approx Swivel


Tie secure knot
Please use the knot diagram (above) to ensure a secure fixing, double up string for added strength

Swivel halfway

Pull out each section of the 7m telescopic launch pole and twist to lock in place



Assemble the kite by inserting rods into pockets and rubber connections



Metal joining ferrule

Connect rods through loop as shown

Angle pole so that the kite hangs well clear to avoid wrapping around the pole

Angle the pole in the opposite direction to prevailing winds



1.5-2m ABOVE CROP

PREVAILING WIND

Ground stake - drive into ground to a depth of approximately 50cm

Green support disc - fits over around ground stake



60cm

Slide pole over ground stake

50cm

If unusually high or gusting winds are forecast, the kite should be taken down to avoid damage